

Solarshop Control Charger

Series solar charge controller



Features for LED indicator controllers:

1. Intuitionistic LED indicators show the current system battery capacity, charging and discharging state of the battery.
2. Protection functions as overcharging, over discharging, overload and reversed connection.
3. PWM charging method makes the charging efficiency increase by 3% to 6%, compared with non-PWM charging.
4. The parameters of charging and discharging have been set during the production (special parameters need to be told)

Features for LCD display controllers:

1. Vivid LCD graphic symbols
2. Protection as battery reverse-discharge protection, battery low voltage disconnection(LVD), battery reverse connection protection, over-current protection
3. Simple button operation make it easy to set the operation mode of load
4. PWM charging mode with 4 stages(bulk, absorption, float and equalized).
5. Adaptable to Sealed, GEL, Flooded and other customized battery type.
6. Automatic identification of system voltage level
7. Adjustable charge-discharge parameters
8. Automatic temperature compensation

STORE ENERGY TODAY,
KEEP BILLS AWAY!

Solarshop Control Charger

Series solar charge controller



STORE ENERGY TODAY,
KEEP BILLS AWAY!


	AUTO 10 Ah	คอนโทรลล์ชาร์จเจอร์อัตโนมัติ ขนาด 10 แอมป์ 12/24 โวลต์
	AUTO 20 Ah	คอนโทรลล์ชาร์จเจอร์อัตโนมัติ ขนาด 20 แอมป์ 12/24 โวลต์
	SLC-GP2410E	คอนโทรลล์ชาร์จเจอร์อัตโนมัติ ขนาด 10 แอมป์ 12/24 โวลต์ + USB
	SLC-GP2420E	คอนโทรลล์ชาร์จเจอร์อัตโนมัติ ขนาด 20 แอมป์ 12/24 โวลต์ + USB
	SLC-GP2430E	คอนโทรลล์ชาร์จเจอร์อัตโนมัติ ขนาด 30 แอมป์ 12/24 โวลต์ + USB
	SLC-GP4830C	คอนโทรลล์ชาร์จเจอร์อัตโนมัติ ขนาด 30 แอมป์ 48 โวลต์ + USB
	SLC-GP2450E	คอนโทรลล์ชาร์จเจอร์อัตโนมัติ ขนาด 50 แอมป์ 12/24 โวลต์ + USB
	SLC-GP2460E	คอนโทรลล์ชาร์จเจอร์อัตโนมัติ ขนาด 60 แอมป์ 12/24 โวลต์ + USB
	SLC-GP4860C	คอนโทรลล์ชาร์จเจอร์อัตโนมัติ ขนาด 60 แอมป์ 48 โวลต์ + USB
	SLC-GP1220	คอนโทรลล์ชาร์จเจอร์อัตโนมัติ ขนาด 20 แอมป์ 12 โวลต์ พร้อมหลอดไฟ 2 วัตต์ + USB

Solarshop Control Charger

SLC-GP2410E / SLC-GP2420E / SLC-GP2430E



Solar Charge Controller User Manual




Please read this manual carefully before use. This manual is subject to change without notice, and the company's interpretation of it shall prevail!

Solarshop Control Charger

SLC-GP2410E / SLC-GP2420E / SLC-GP2430E



Solar Charge Controller User Manual



Please read this manual carefully before use. This manual is subject to change without notice and the company's interpretation of it shall prevail!

Explicitly displayed. Most parameter values can be set to meet various applications.

2.2 Function

- (1) Multi-stage PWM charging mode.
- (2) Preset charging parameters for three battery types.
- (3) Detecting mode for battery voltage level is adjustable.
- (4) Charging and discharging parameters are adjustable.
- (5) Temperature compensation is applied.
- (6) Various controlling mode for load.
- (7) Optional communication function.
- (8) Protection against reverse connected solar panel and input over-current.
- (9) Protection against under-voltage, over-voltage, reverses connection and reverse discharge of battery.
- (10) Protection against over-current of load.
- (11) Protection against internal over-heat.

3

3.2 Installation Procedure

Please make sure battery and solar panel are disconnected to controller, and do not contact the positive and negative terminals of solar panel and battery at the same time in case of electric shock.


A free space of 15cm on all sides must be provided for better heat dissipation. Current density control system wiring cables within the 4A / mm².

- (1) Make sure installation site meets safety requirements first.
- (2) Make sure voltage of solar panel and battery are compatible with controller.
- (3) Connect battery to controller and check whether the LCD display is on, if not, please solve the problem as mentioned in chapter 5.2.
- (4) Connect solar panel to controller accordingly. If there's sunlight, controller starts charging battery immediately and charging indicator arrow on LCD is on.
- (5) Connect load to controller.

5

4.2 LCD Interfaces

4.2.1 Startup Interface



- (1) Startup interface: the interface when system is powered on by which you check whether the LCD is in good condition
- (2) System voltage: battery voltage detected by controller
- (3) Rated current: Rated charging and discharging current of controller

7

1. Safety Instruction

- (1) Please keep installation site clear of flammable or explosive, or corrosive gases and dust etc.
- (2) Please protect the controller from direct sunlight or rain.
- (3) Please prevent foreign object or liquid approaching controller.
- (4) Please contact technical personnel to dismantle or repair the controller.
- (5) Please don't put metal object beside battery.
- (6) Please do not touch terminals or back plate of controller in case of electric shock or scald.


2. Product Introduction

2.1 Profile

This series is a new series of intelligent multi-purpose solar charge controllers. Its innovative design makes it easy to install and quite user-friendly. Optimized charging and discharging management extend the service life of batteries considerably. Meanwhile, parameters are

3. Installation


3.1 Dimension and Circuit Layout



4

4. Operating Instruction

4.1 Symbols




1. LVR ABSORB LVD FLOAT P(PM)
2. Day and night
3. Battery type: FLD GEL SLD Null means User
4. Charging
5. Error
6. Discharging
7. Time
8. Capacity
9. Load state
10. Unit
11. Data display area

6

(3) In interface "Ah-Battery Charge Meter" OR "Ah-Battery Discharge Meter" by long pressing (>3S) , data is cleared.

(4) In "Battery voltage" interface, by long pressing and simultaneously until the screen is fully bright controller is restored to factory defaults.

4.2.3 Battery, Communication



In main loop "Battery voltage" interface, by long pressing (>3S) you can access secondary one-way loop. In secondary loop, by short pressing you can circulate interfaces, and by short pressing you can change values, while a long-pressing (>3S) enables data saving

9

Solarshop Control Charger

SLC-GP2410E / SLC-GP2420E / SLC-GP2430E




and exit, and a 20s absence of operation bring you to main loop interface with data unsaved.

- (1) Battery type: Four battery types are preset which are GEL, SLD, FLD and USr. Only parameters of USr type are adjustable.
- (2) Battery voltage level identification: automatic identification (AUO), fixed 12V, fixed 24V, fixed 36V and fixed 48V. Different types of controllers automatically recognize different voltage ranges, and please refer to real controller.
- (3) Controller Communication SN: the number can be set in the range of 1 to 99, the default value is 1. (For controller with communication function only.)
Controller restarts automatically to update data after battery type and voltage level are set.

10

4.2.4 Controller SN




In main loop "Temperature" interface, by long pressing (>3S) you can access secondary one-way loop. In secondary loop, by short pressing you can circulate interfaces and a long-pressing (>3S) or a 20s absence of operation, you can exit.

Controller communication SN: composed of 8 digits, every 2 digits displayed sequentially, eg:-- 88 56 73 24 .

11

4.2.5 Charging Settings




In main loop "input current" interface, by long pressing (>3S) you can access secondary one-way loop. In secondary loop, by short pressing you can circulate interfaces, and by short pressing you can change values, while a long-pressing (>3S) enables data saving and exit, and a 20s absence of operation bring you to main loop interface with data unsaved.

Note: Only parameters of USr type are adjustable.

12

4.2.6 Load Working Mode



In main loop "Output current" interface, by long pressing (>3S) you can access secondary one-way loop. In secondary loop, by short pressing you can circulate interfaces, and by short pressing you can change values, while a long-pressing (>3S) enables data saving

13

and exit, and a 20s absence of operation bring you to main loop interface with data unsaved.

3 working mode for load as below:

Code	Working mode for load
L00	Regular controller mode (Mode 0)
L01	Light control with switch-off point at night and switch-on point before dawn (Mode 1)
L02	Light control mode (Mode 2)

Different load controlling modes defines parameters adjustable and interface displayed.

14

		Make sure battery capacity is not too low. Make sure voltage of other battery charger connected to battery is not too high When battery voltage is 0.5V lower than defined overvoltage protection point, load switched on automatically by controller
E05	Battery charging switched off due to over-temperature of controller	Allow the controller to cool down and restart charging automatically
E06	Over-voltage of solar panel	Make sure voltage of open circuit is not too high and reduce panel in series connection
E07	Charging switched off by controller due to excessive solar panel current	Check power of solar panel and reduce solar panel quantity in parallel connection and wait for 2 mins for restart charging

16

5 Fault Management

5.1 Error Code and Correction

Error code	Cause	Correction
E01	LVD	Manually recharge the battery
E02	Excessive load current and load switched off	Reduce load current at load output, and switch on load manually or wait for 10 mins for auto switch-on by controller.
E03		
E04	HVD	Make sure connection between battery and controller is good. Make sure battery capacity is not too low.

15

5.2 Failure and Correction

Failure	Correction
No sign on LCD initialization	Make sure no reverse connected battery. Make sure connection between battery and controller is good. Make sure circuit of battery switched on. Make sure fuse protector connected.
No charging current	Make sure no reverse connected solar panel. Make sure connection between solar panel and controller is good with no open circuit.
Load not work	Make sure there's no reverse connected load. Make sure controller is not in protection against overload, short circuit, under-voltage or overvoltage.
Load not switched on at preset point	Make sure load controlling mode is correctly set. Make sure battery voltage not too low.

17

Solarshop Control Charger

SLC-GP2410E / SLC-GP2420E / SLC-GP2430E



Load unable to be switched on at night in Light control mode	Make sure load controlling mode is correctly set. Check solar panel not illuminated by other light sources at night.
--	---

6 After Sales Service

6.1 Warranty

Manufacturer provides

- (1) One-month warranty of free replacement is provided for this product commencing from the date of purchase.
- (2) One-year warranty of free repair is provided for this product commencing from the date of purchase.
- (3) Lifetime warranty of payable repair is provided for this product commencing from the date of purchase.

18

Free guarantee service will not be provided to the said equipment if

- (1) It has been damaged through transportation or storage or
- (2) It has been operated otherwise than in accordance with the instructions or
- (3) Any unauthorized repair or modification has been carried out on the unit or
- (4) It has been damaged through natural calamities

6.2 Return & Repair

Please contact customer service before return controller for repair and send controller together with original invoice and associated information like controller model, SN, cause. After receiving return controller, customer service will contact you to confirm cost and time etc. Please note any cost of transportation is on the account of purchaser.

19

7 Technical data

Model	20DU	30DU	2048D	3048D
Input				
PV voltage	≤50V	≤50V	≤100V	≤100V
Rated Current	20A	30A	20A	30A
Output				
System Voltage	12V/24V Auto	12V/24V Auto	48V	48V
HVD	16.00V ×1/×2/×3/×4			
Rated discharge current	20A	30A	20A	30A
No-load loss	≤13mA		≤25mA	
Charge loop voltage drop	≤0.21V	≤0.24V	≤0.25V	≤0.25V
Discharge loop voltage drop	≤0.12V	≤0.1V	≤0.12V	≤0.10V
Charging mode	PWM Multi-stage (bulk, absorption, float, equalized)			

20

Voltage of float charging	13.8V(13V~15V)×1/×2/×3/×4
Voltage of absorption charging	14.4V(13V~15V)×1/×2/×3/×4
Duration of absorption charging	2hs
Voltage of equalized charging *	14.6V(13V~15.5V)×1/×2/×3/×4
Duration of equalized charging	2hs
LVD	10.8V(10V~14V)×1/×2/×3/×4
LVR	12.6V(10V~14V)×1/×2/×3/×4
Load working mode	Regular control mode Light control with switch-off point at night and switch-on point before dawn Light control mode
Light control voltage	5V(1V~10V)×1/×2/×3/×4
Battery type	GEL, SLD, FLD and USr(default)
USB	5V 1A None

21

Other				
Man-machine interface	LCD, 2 buttons			
Wiring	PCB terminal, ≤6mm ²	PCB terminal, ≤16mm ²	PCB terminal, ≤6mm ²	PCB terminal, ≤16mm ²
Working temperature	-20 ~ +50 °C			
Storage temperature	-30 ~ +60 °C			
Working humidity	10% ~ 90%, no condensation			
Dimension	188 x 95 x 40mm			
Net Weight	355g	360g	355g	360g
IP Code	IP30			
Optional function	Remote communication , TTL, standard ModBus protocol			

22

Battery type:

Battery type	Voltage of float charging (V)	Voltage of absorption charging(V)	Time of absorption charging(h)	Voltage of equalized charging(V)	Time of equalized charging(h)	Interval of equalized charging(day)
GEL	13.8	14.2	2	--	-	--
Sealed	13.8	14.4	2	14.6	2	28
Flooded	13.8	14.6	2	14.8	2	28
User	13.8	14.4	2	14.6	2	28

23